

# INSTEON®



## Home Kit Quick Start Guide

# INSTEON Hub

Status LED



Idle



Linking



Unlinking



Ethernet Port

Power



Factory Reset Button




Ethernet  
Cable

Power  
Cable

Use only the cables provided.

1


Download and install the latest INSTEON for Hub App from your device's app store.



Scan the QR Code  
for the free app.


2

Launch the app and follow the instructions to setup your INSTEON Hub.



3

Follow the on-screen instructions to add your devices.



## Remote Access

You can monitor and control your devices when away. To configure remote access, go to Settings > House > Remote Access Guide.




We're here to help. Contact INSTEON Support at 866.243.8022.

## On/Off Module

 On

 Off

Status LED




Up to 1,800W/15A maximum load




Learn more about On/Off Module  
[insteon.com/onoffmodule-qsg](https://www.insteon.com/onoffmodule-qsg)

# Motion Sensor



Wall Mount  
Retention Slot





(Cover Removed)



Learn more about Motion Sensor  
[insteon.com/motionsensor-qsg](http://insteon.com/motionsensor-qsg)



## Open/Close Sensor




(Cover Removed)



Learn more about Open/Close Sensor  
[insteon.com/openclosesensor-qsg](https://www.insteon.com/openclosesensor-qsg)


# Thermostat

Temperature Adjust



Mode

Status LED





Set Button



Learn more about Thermostat  
[insteon.com/thermostat-qsg](http://insteon.com/thermostat-qsg)

# WiFi Camera



Learn more about WiFi Camera  
[insteon.com/wificamera-qsg](http://insteon.com/wificamera-qsg)

# INSTEON Support

For video tutorials, product support and more, visit: **[insteon.com/support](http://insteon.com/support)**.

