

INSTEON




INSTEON Mini Remote - 4-Scene Kit Quick Start Guide

INSTEON Mini Remote - 4-Scene Kit









Charging

Fully charge your Mini Remote before use. Your Mini Remote battery lasts 9-12 months between charges with average use.





Linking

Tap the button you wish to use and then press and hold the set button until the Mini Remote beeps.



Make sure the device you wish to control is ON and then press and hold its set button until it double-beeps.







Learn More

For the complete Owner's Manual, video tutorials, product support and more, visit: **insteon.com/support.**





