


Getting Started with the Insteon Starter Kit

What's included in your Insteon Starter Kit




Mini Remote



Dimmer Module

Button A



Outdoor On/Off Module

Button B



Incandescent
& Halogen



Dimmable
CFL



Dimmable
LED



CFL



LED

Only connect lamps with dimmable
bulbs to Dimmer Module.



Expand your Insteon system with
additional sensors, wall switches,
cameras and more.

insteon.com/products




insteon.com/support

Have questions? We have answers.


For more documentation, visit:
insteon.com/get-started-gma1

1 Turn on your lamp and connect its power cord to Dimmer Module.




Only connect lamps with dimmable bulbs to Dimmer Module.


2 Plug Dimmer Module into a power outlet.



3 Turn on your lamp or outdoor fixture and connect its power cord to Outdoor On/Off Module.




4 Plug Outdoor On/Off Module into a power outlet.




Only connect to a GFCI-protected outlet when used in a wet location.

5 Turn on Mini Remote by sliding the power switch to the right.



6 Tap to turn on and off, press and hold to brighten or dim. Buttons C and D can be used for additional Insteon devices.

Button A
Dimmer Module
Button B
Outdoor On/Off Module



Recharge Mini Remote every 6 to 8 months with Micro USB.

