
INSTEON




INSTEON Wireless Switch
Quick Start Guide

INSTEON Wireless Switch




Charging

Fully charge your Wireless Switch before use. Your Wireless Switch battery lasts 9-12 months between charges with average use.



Mounting

You can place your Wireless Switch in-line with existing switches using the Wall Mount Kit (Sold Separately).







Do not mount Wireless Switch **over** an open junction box.

Linking

Tap the top of the switch and then press and hold the set button until the Wireless Switch beeps.



Make sure the device you wish to control is ON and then press and hold its set button until it double-beeps.





Learn More

For the complete Owner's Manual, video tutorials, product support and more, visit: **insteon.com/support.**





